

AD1


AF7

AB2

AF3

AC2

AH1



a	b	c	d	e	f	g	h	i	k	l
⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕
⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕
⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕
⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕	⊕

TELEFUNKEN DIRIGENT

MF = 484 kHz

1936/37

AZ1